

# REFRESH FABRIC DISPLAY CONNECTION METHODS

This instructional sheet is designed to show you the connection methods of the Refresh product and how they interact.

## 1. Vertical to Horizontal connection

Fig. 1a





Fig. 1b

As you can see from the images, you take the horizontal bar and slide the end connector into one of the sides of the vertical, whilst making sure the thumb screw has been loosened so they can slide together easily (fig 1a). Be careful not to loosen the thumb screw too much. When doing this the ears of the horizontal should always be facing out. The bars are then secured in place by simply tightening the thumbscrew. Make sure the horizontal is flush with the end of the vertical (fig 1b).

## 2. Vertical to Vertical connection




Fig. 2a




Fig. 2b

## RULES AND TIPS

- ◀ a. The vertical without the connector should always be at the bottom to make the connection easier.
- ▼ b. Loosen the thumbscrew in the next bar first but never so the thumb screw comes out, make sure the thumb screw is done up tightly but do not over tighten.

The verticals simply lock together by sliding one onto another (fig 2a) until they fully meet (fig 2b). A pre-set connector insert in one of the vertical bars allows each piece to locate together swiftly and easily. See point (a) under 'Rules and Tips'.

## 3. Horizontal to Horizontal connection





Fig. 3a

Fig. 3b



The horizontal bar connection is used when your stand is displaying fabric. Release the thumb screw from the bar that the 20mm tube is going into, in order to make sure they connect together easily. Push the 20mm tube (fig 3a) into the next horizontal bar until they meet (fig 3b) and turn the thumb screw to secure into place. See point (b) under 'Rules and Tips'.

These are the only three points needed to know to make a complete Refresh structure.